

## HOW to Connect the FM-137 Keypad to a YG-150/U/E or YG-200/U/E

Follow the directions in the FM-137 keypad for “wired installation of the keypad”

Connect each of the relay output terminals on the FM-137 keypad to one of the O/S/C terminals on the YG-150/200 control board.

Connect the positive (+) AC/DC Power in terminal on the FM-137 to the terminal marked (12) on the YG-150 / 200 control board.

Connect the negative (-) AC/DC Power in terminal on the FM-137 to the terminal marked GRND on the YG-150 / 200 control board.

Follow the rest of the directions in the FM-137 manual for programming the codes.